



Order Instruction for EP series




Note:

- For outage mode selection, capacitor reset mode is only available for EP200 and below sizes. Please refer to Page 21-23 for parameters and outline drawings.
- The customized functions are available for EP200 and above sizes.

Order Instruction for EA series



Order Instruction for EPQ series



Note:

- For outage mode selection, capacitor reset mode is only available for EPQ115/EPQ215/EPQ315. Please refer to Page 21-23 for parameters and outline drawings.
- The customized functions are available for EPQ415 and above sizes.